








Bild	Artikelnummer	Produkt	Preis
	10160000	KW Höherlegung Ford Custom V710 / Volkswagen Transporter T8	1.385,00
	10720108	Tacho Kalibrierkit	589,00
	14160000	Schutzplatte Motor Ford TOURNEO Custom V710 / Volkswagen Transporter T8	1.262,81
	14160001	Schutzplatte Differential Hinterachse Ford Custom V710 / Volkswagen Transporter T8	253,32
	14160002	Schutzplatten-Set Tank Ford Custom V710 / Volkswagen Transporter T8	1.250,94
	14160003	Schutzplatte rechter Unterboden Ford TURNEO Custom V710 / Volkswagen Transporter T8	624,06
	14160004	Rockslider-Set L1 Ford Custom V710 / Volkswagen Transporter T8	697,70



14160005

Befestigungsleiste links L1 Ford
Custom V710 / Volkswagen
Transporter T8

287,40



14160006

Befestigungsleiste rechts L1
Ford Custom V710 /
Volkswagen Transporter T8


287,40



14160007

Schutzplatte Motor Ford
TRANSIT Custom V710 /
Volkswagen Transporter T8

1.262,81



14160008

Kühlerschutzgitter für
Motorschutz Ford Custom V710
/ Volkswagen Transporter T8

240,00