



<b>Volkswagen Amarok 4-cyl. and V6</b>			
<b>Stone chip guard "Desert", rear axle</b>			
Nummer:	1470 0008	Stand:	10.2017
Revision:	04	Sprache:	EN

## Installation guide 1470 0008

### **This installation guide applies to this part n°/description:**

1470 0008 Amarok 4-cyl. and V6 – Stone chip guard „Desert“  
made of stainless steel for both the shock absorbers of the rear axle



<b>Volkswagen Amarok 4-cyl. and V6</b>			
<b>Stone chip guard "Desert", rear axle</b>			
Nummer:	1470 0008	Stand:	10.2017
Revision:	04	Sprache:	EN

## Important

To ensure proper function and optimal quality of our parts, their installation must be done in accordance with this installation guide and according to Volkswagen manufacture's specifications in a professional workshop. SEIKEL GmbH and its employees shall not be responsible for damage and its consequences of any nature, which are caused due to non-observance or ignorance of these guidelines. Warranties shall be void for incorrectly performed installations.

## Installation guide

Please refer to the Volkswagen instructions for the exact working steps as well as the tightening torques. In case of deviation, our specifications shall be applicable.

## NOTE!

**All the drill holes and breakthroughs must be deburred from both the sides. Metal swarfs are to be removed / vacuumed up immediately, and it has to be ensured that no swarfs fall into the hollow space in the body!**

**Apply paint (as per current valid Volkswagen repair manual "Paint", refer to ELSA):**

1. Apply wash primer and allow it to dry in accordance with the item description. A hot-air dryer can be used, if necessary. We recommend: 1k Wash primer LLS MAX 106 M2.
2. Apply filler and allow it to dry in accordance with the item description. A hot-air dryer can be used, if necessary. We recommend 2K-HS filler LLS MAX 202 M2.
3. Apply base coat on visible areas based on the vehicle-specific varnish and allow base coat to dry in accordance with the item description. A hot-air dryer can be used, if necessary.
4. Protect all cutting edges, hollow spaces or drill holes additionally with anti-corrosion wax, if required using a small brush. We recommend transparent preservative wax AKR 321 M 15 4.



<b>Volkswagen Amarok 4-cyl. and V6</b>			
<b>Stone chip guard "Desert", rear axle</b>			
Number:	1470 0008	Stand:	10.2017
Revision:	04	Sprache:	EN



## Parts list

- 2x stone chip guard for shock absorber rear axle



## Instructions

Place jack below axle casing, unscrew shock absorber screw at the bottom and mount stone chip guard as shown in the image.



Adjust the distance from stone chip guard to shock absorber to 50 mm.

Tighten lower shock absorber screw connection as per manufacturer's specifications.

**Note:** While doing this, the vehicle must be on the floor.